# TOWN OF HUNTINGTON

# PUMP-OUT

# LOCATIONS AND DIRECTIONS FOR USE

**Locations:**

- Gold Star Battalion Beach right of the beach on the "T" float (to the left of Coindre Hall)
- Cold Spring Harbor at Powles Marina
- Halesite North - Halesite Marina (in between Ketewomoke and Halesite Dock)
- Halesite South - Behind the Harbor Club near the James Joseph tie up
- Mill Dam Marina located next to the ramps

** If you are using Cold Spring Harbor, Gold Star or Mill Dam Marina pump-outs and the unit is not pumping there could be a possibility they are full. Please notify the Harbormaster at 631-351-3255

**Directions for use: (Cold Spring Harbor, Halesite North and Mill Dam)**

1. Uncoil the hose
2. Connect to your holding tank on your boat
3. Press the green button
4. Slowly open up the valve
5. It will create suction and start pulling waste from the holding tank
6. When complete, press red button
7. Close valve
8. Recoil the hose

**Directions for use: (Halesite South, Gold Star Battalion Beach)**

1. Uncoil the hose
2. Connect to your holding tank on your boat
3. Press the red button
4. Wait 90 seconds
5. Hit the green button
6. When complete, close the valve
7. Recoil the hose

The pump-out BOAT runs from Memorial Day weekend until Columbus Day.
Weekends only 9am – just before dusk (Weather permitting)